

# Loft

Béton brut



N° 33450

**Enduit aspect béton spécialement conçu pour une ambiance urbaine et moderne. Sa facilité d'utilisation et son aspect très "tendance" vont séduire les adeptes d'un style épuré et sophistiqué.**



les Décoratives

# Loft Béton brut

**Revêtement décoratif intérieur, mat, lavable\*  
et décollable avec une décolleuse à papiers peints.  
(\*lavable si protégé avec le Protecteur incolore)**

## Préparation

**Loft** s'utilise sur tous supports sains, propres et secs. Appliquez une couche de **Primaire d'accrochage enduit décoratif** en respectant les recommandations indiquées sur le contenant. Ne pas appliquer sur papier peint.

## Application

**Loft** est livré avec un sachet de poudre blanche à mélanger avec l'enduit. Ce n'est pas une obligation mais nous préconisons le mélange, car la poudre va apporter de manière aléatoire, des petites notes de lumière et ainsi faire vivre votre mur. Sans la poudre, l'effet sera plus sage et uniforme mais tout aussi séduisant. Munissez-vous de gants lors de la manipulation de la poudre blanche. Versez la poudre dans un récipient, ajoutez 200ml d'eau et attendez  $\pm 10$ mn avant de mélanger. Incorporez la solution dans le seau de **Loft** et mélangez l'ensemble avec un mélangeur et une perceuse électrique (800W minimum).

**Important : Assurez-vous de bien avoir mélangé au fond et sur les bords du contenant pour éviter des différences de couleur.**

Une fois le mélange effectué, le produit doit être utilisé dans un délai de 48h, et conservé dans le contenant soigneusement fermé. Nous vous conseillons toutefois de réaliser votre pièce rapidement et en une seule fois, afin d'éviter d'éventuelles nuances. Appliquez le **Loft** à l'aide d'une truelle d'inox en réalisant des mouvements croisés, souples et irréguliers pour obtenir un aspect plus ou moins structuré (avec plus ou moins de relief). Laissez prendre  $\pm 2$ heures, puis humidifiez légèrement votre surface ( $\pm 3$ m<sup>2</sup> à la fois) avec une éponge, avant d'écraser les surépaisseurs avec la tranche de votre taloche inox et obtenir ainsi l'aspect béton brut.

## Protection

Si vous souhaitez une surface résistante à l'eau et aux taches, faites une application de **Protecteur mural incolore**.



N° 3300-2.5L



N° 3307



6. Stockholm



4. Milan

**3 Coloris**

**Format : 12 kg**

**Rendement :  $\pm 15$ m<sup>2</sup>**

**(130pieds<sup>2</sup>)**

Produit distribué par Waxine inc.  
1-877-651-1929 [www.waxine.com](http://www.waxine.com)

# Loft

Raw Concrete



N° 33450

**A concrete-look coating especially designed for a modern and urban ambiance. Its fashionable, distinctive look, as well as its easy-to-apply properties will seduce any fan of a sophisticated and refined style.**



les Décoratives

# Loft Raw Concrete

**Interior decorative coating, mat, washable\* and removable with a wallpaper stripper. (\*washable if protected with a Clear wall protector)**

## Preparation

**Loft Raw Concrete** can be used on any dry and clean surface. Apply a coat of **wall coating primer** by following the instructions on the package. Do not apply on wallpaper.

## Application

**Loft Raw** comes with a small bag of white powder that has to be blended with the actual coating. This added element will give the covered wall nuances and depth like real concrete. Without the powder, the effect will be slightly duller and more uniform but still stunning. Pour the white powder into a dry container, add 200ml of water and wait more or less 10 minutes before mixing. Make sure to wear gloves during this process. Then, incorporate the solution into the Loft Raw container and blend it with a mixer and an electric drill (800w minimum).

## Important:

Make sure you mix the two products really well, including the bottom of the container as well as its sides to avoid having different colors. Once mixed the product has to be used quickly ( $\pm 48$  hours) and kept in its closed container. We recommend that you perform your work promptly and all at once, to avoid having different colours. Using a Stainless Steel Trowel, apply a thin coat (2mm) to your well prepared wall. Once you have well covered your surface, come back with your cleaned tool and create a pattern. Make sure you keep regular, even strokes for the whole wall. Let the LOFT Raw dry for  $\pm 2$  h. Then, with a sponge or a water sprayer, lightly humidify the surface (work on  $\pm 30$ sqft at one time). With your stainless steel trowel, scrape off any undesired peaks and polish the softened surface using circular movements. This step will create the smooth raw concrete look.

## Protection (Optional)

If you wish to make the surface water and stain resistant, apply one coat of **Clear Protector N° 3307**



N° 3300-2.5L



N° 3307



6. Stockholm



4. Milan

**2 colours**  
**Size: 12Kg**  
**Coverage: 130 Sq.ft**  
**(15m<sup>2</sup>)**

Distributed by Waxine inc.  
[www.waxine.com](http://www.waxine.com)